




PACIFIC PREMIER TRUST PROPERTY



LINE TABLE		
LINE	LENGTH	BEARING
L1	111.65	S87°30'00"W
L2	59.40	S88°30'00"W
L3	102.30	N03°41'04"E
L4A	57.14	N04°56'04"E
L4B	81.46	N04°56'04"E
L5	132.00	N04°48'56"W
L6	145.20	N06°48'56"W
L7	67.52	N66°56'37"E
L8	133.63	N77°08'37"E
L9	133.74	N70°03'51"E
L10	89.03	S88°42'15"E
L11	132.00	S67°14'40"E
L12	155.10	S66°59'40"E
L13	132.00	S58°20'02"E
L14	84.73	S23°56'27"W
L15	126.00	S20°20'48"W
L16	37.73	S24°26'56"W
L17	68.46	S28°26'54"W
L18	91.87	S33°14'46"W
L19	22.60	S43°10'23"W
L20	99.70	S48°45'25"W
L21	37.32	S20°20'49"W
L22	79.34	S20°20'48"W
L23	44.42	S24°26'55"W
L24	18.72	S43°10'25"W